

Low Voltage Standard CMOS Opamp Design Techniques

Student name: Eliyahu Zamir

Student number: 961339780

Course: ECE1352F

Professor: Khoman Phang

1. Abstract

In a never-ending effort to reduce power consumption and gate oxide thickness, the integrated circuit industry is constantly developing smaller power supplies. Today's analog circuit designer is faced with the challenges of making analog circuit blocks with sub 1V supplies with little or no reduction in performance. Furthermore, in an effort to reduce costs and integrate analog and digital circuits onto a single chip, the analog designer must often face the above challenges using plain "vanilla" CMOS processes. This paper will examine some of the specific challenges of, and proposed solutions to, designing one of the most popular and widely used analog building blocks, the Operational Amplifier (Opamp).

2. Introduction

Opamps are among today's most widely used circuit blocks. They can be used as summers, integrators, differentiators, comparators, attenuators and much more. Defined generally, an Opamp is a high-gain differential input amplifier [1]. Designers have been trying to integrate these versatile circuit blocks into the rest of their circuitry since the mid-1960s [2]. The μ A709 was the first Opamp designed on an integrated circuit.

In an effort to reduce cost and space and improve performance, designers are integrating more and more circuit blocks, both analog and digital, onto a single chip. In order to reduce power dissipation, it is advantageous, at least for digital circuit blocks, to implement these "mixed-signal" chips in a standard CMOS process. In a

further effort to reduce power dissipation in digital circuit blocks, it is advantageous to reduce the supply voltage V_{dd} . For a standard CMOS inverter, power dissipation may be expressed as [3]:

$$P_{avg} = C_{load} \times V_{dd}^2 \times f_{clk} \quad (2.1)$$

In an effort to increase the intrinsic gain of CMOS devices, the trend in the MOSFET design industry is to shrink the gate oxide thickness, T_{ox} . Unfortunately, as T_{ox} is reduced, the MOSFET device's tolerance for high voltage levels at the gate is also reduced. This means that, for reliability purposes, it is advantageous to reduce the maximum voltage supply V_{dd} .

This trend in reducing the supply voltage means that analog designers face challenges such as reduced input common mode range, output swing and linearity. Part of the problem is that V_{T0} does not scale in a linear fashion with the reduction in minimum device length. V_{T0} is given by the following expression:

$$V_{T0} = V_{fb} + 2\phi_F + \left(4e\epsilon_r N_a \phi_F\right)^{\frac{1}{2}} \frac{1}{C_{ox}} \quad (2.2)$$

Most of the values in equation 2.2 remain relatively constant as minimum process lengths and supply voltage are scaled down. Therefore, a decrease in V_{T0} can usually only be brought about by a decrease in N_a or by an increase in C_{ox} . Unfortunately for the designer, V_{T0} does not tend to decrease at the same rate as V_{dd} .

Some fabs do offer low V_{T0} processes specially suited for analog blocks. However, they tend to cost more than standard CMOS processes. It is therefore desirable to use low voltage design techniques, in order to be able to implement analog circuit blocks using standard CMOS processes.

This paper will discuss techniques for implementing low supply voltage Opamps using a standard CMOS process. It will begin by presenting some of the more traditional low voltage Opamp design techniques, such as the folded cascode structure. The paper will then present some more recent developments in Opamp design, such as Floating Gate CMOS (FGCMOS) and Bulk driven input stages.

3. Low Voltage Opamp Solutions

3.1. Folded Cascode Opamp

The typical differential pair, shown in figure 1, normally consists of 2 transistors connected in a common source amplifier configuration. The differential gain of this amplifier is given by:

$$A = -gm_{1,2}R_{out} \quad (3.1.1)$$

In an effort to increase the gain of this differential pair, it can be connected in cascade with a common gate amplifier, as shown in figure 2. This is known as a cascode configuration. Its differential gain is given by:

$$\begin{aligned} A_{cascode} &= A_{comsource} \times A_{commongate} \\ A_{cascode} &= -gm_{1,2}r_{o(1,2)} \times gm_{3,4}r_{o(3,4)} \end{aligned} \quad (3.1.2)$$

This very large gain comes at a price. The extra transistors $M_{3,4}$ require an extra V_{eff} from the total supply headroom budget. If however $M_{3,4}$ are chosen as PMOS devices and placed in the folded cascode configuration, shown in figure 3, then at the cost of some extra current, this configuration takes up the same amount of voltage headroom as that of the simple differential pair shown in figure 1.

In the case of an NMOS input differential pair, the input transistors must have a bias high enough so that the tail current source transistor remains in the active region. In the case of a PMOS input differential pair, the input must be biased low enough so that the tail current source transistor remains in the active region. In other words,

$$\begin{aligned} V_{cm(\min)} &= V_{eff} + |V_t| \leftarrow NMOS \\ V_{cm(\max)} &= V_{dd} - (V_{eff} + |V_t|) \leftarrow PMOS \end{aligned} \quad (3.1.3)$$

Given a typical modern process with a $V_{tn}=0.5V$ and a V_{eff} of $0.2V$, this means that the minimum input common mode voltage is limited to about $0.7V$. This configuration is clearly not suitable for sub $1V$ supply applications. One solution is to use a complementary input differential pair, such as the one suggested Roewer et al [5].

The complementary input Opamp discussed in the above paper is shown in figure 4. The input of this Opamp has both an NMOS and a PMOS differential pair. In effect, there are two Opamps at the input, as shown in figure 5. The output signals from these Opamps are then summed together using a class-AB output stage formed by transistors $M_{7,8}$. When the input common mode level approaches ground, the NMOS input devices turn off, leaving only the PMOS input devices to contribute gain to the Opamp. When the input common mode level approaches V_{dd} , the PMOS devices turn off, leaving only the NMOS devices to contribute gain to the Opamp. Unfortunately, the complementary input configuration may contain an undesirable “dead-zone” in the input common mode range. In this “dead-zone”, the DC bias level is too high for the PMOS input, but not high enough for an NMOS input. The designer must ensure that there is sufficient overlap of $V_{cm(in)}$ where both the PMOS and NMOS differential pairs are active.

For example, using a typical modern process where $V_{tn}=0.5V$, and $V_{tp}=-0.7V$, and the current sources are biased to have a $V_{eff}=0.2V$, equation (3.3) gives us;

$$V_{cm(min N)} = 0.7V \leftarrow \text{Limited by NMOS diff pair}$$

$$V_{cm(max P)} = V_{dd} - 0.9V \leftarrow \text{Limited by PMOS diff pair}$$

With a 1V supply, this would leave a “dead-zone” between 0.1V and 0.7V. Clearly, the complementary input stage is also not ideal for ultra-low supply voltages.

In the following sections some more recent Opamp design techniques will be presented. These circuits are much more suitable to sub 1V supply environments.

3.2. Floating Gate CMOS (FGCMOS) Opamps

Floating gate transistors have mainly been used in EPROM and EEPROM circuits [6]. Shown in figure 6, the FGCMOS transistor is AC coupled at the gate. The transistor's gate then has a charge placed on it, using either UV radiation, or high voltage pulses (e.g. 20V) [6], which biases the device at the desired level. This charge can remain constant without any need for reprogramming for over 10 years [6]. Because the transistor is now AC coupled, the input common mode voltage can be at almost any level.

The FGCMOS "pseudodifferential" pair proposed in [7] is shown in figure 7. Here, inputs V1 and V2 are connected to the gates of FGCMOS $M_{1a,1b,2a,2b}$. Transistors $M_{1a,2a}$ are in a diode connected differential pair arrangement, which mirrors half of bias current I_b to the output. Small signal inputs $V_{1,2}$ are amplified and converted into small signal output currents through cascode transistor pairs $M_{1b,1c}$ and $M_{2b,2c}$ respectively. This arrangement allows rail-to-rail input voltage and large differential transconductance gain G_{dm} . Figure 8 shows the experimental transconductance gain achieved for several different bias currents, in a 1.2 μ m process, and with a 1.6V supply. Clearly, this circuit topology is well suited to very low input supply voltages. Unfortunately, this topology has a limited output voltage. In order for all transistors to remain active, the drains of transistors $M_{1c,2c}$ must remain at least

2V_{eff} from ground. If rail-to-rail output voltage is desired, a different approach must be used.

One such approach is the use of FGCMOS transistors in an analog inverter configuration. An FGCMOS differential pair was implemented in [8] using basic analog inverter building blocks, shown in figure 9. When the transistor's gates are programmed such that the inverter is in equilibrium (i.e. V_{out}=V_{dd}/2), it can be shown that [8]:

$$I_p = I_n = I_{bec} \times e^{\frac{k_i}{nU_t} \left(\frac{V_{dd}}{2} - V_{in} \right)} e^{\frac{k_i}{nU_t} \left(\frac{V_{dd}}{2} - V_{out} \right)} \quad (3.2.1)$$

Where I_{bec} is the equilibrium large signal current, k_i=C_i/C_t, and nU_t are constants. V_{out} is then [8]:

$$V_{out} = \left[\frac{(A+1)}{2} \right] V_{dd} - AV_{in} \quad (3.2.2)$$

$$, A = \frac{k_i}{k_t}, k_t = \text{sum of all } k_i$$

Note that for a single input inverter, the gain A=1, and as more inputs are used, gain is decreased. For the differential amplifier shown in figure 10, the maximum gain achievable is A=1/2. This is clearly not very useful for an Opamp in most applications. However, some specialized applications that do not require much gain, such as an Opamp comparator, may still find the FGCMOS differential analog inverter quite useful for ultra-low supply applications.

Another problem faced by all FGCMOS input devices is that their input coupling capacitors tend to take large die areas. Therefore, FGCMOS could prove to be an expensive solution to the low voltage supply challenge. Furthermore, placing capacitors at the input of an Opamp makes it unsuitable for very low frequency operation.

3.3. The Bulk driven amplifier

In the past, analog designers have often taken for granted that a MOSFET transistor is actually a four terminal device. The Bulk terminal is usually ignored and simply connected to ground or Vdd, or tied to the source terminal. Recently, however, it has been discovered that the Bulk terminal may be used as a small signal input in a completely novel family of amplifiers that are very well suited to an ultra-low supply environment.

The Bulk driven input stage, shown in figure 11, modulates the threshold voltage to produce a transconductance gm_b given by [9]:

$$gm_b = \frac{di_D}{dv_{BS}} = \frac{g \times gm}{2\sqrt{2f_F - V_{BS}}} \quad (3.3.1)$$

It can be shown that the gain of a Bulk driven amplifier can actually exceed that of a standard common source input differential stage when [9]:

$$V_{BS} \geq 2f_F - 0.25g^2 \quad (3.3.2)$$

A rail-to-rail input and output Opamp, shown in figure 12, was presented in [9]. With only a 1V supply, this Opamp has 48.8dB gain and a 1.3Mhz unity gain frequency. This design demonstrates that Bulk driven input stages are well suited for ultra-low voltage Opamps.

Unfortunately, the favourable properties of the Bulk driven input stage do not come without their drawbacks. Increasing the input common mode voltage V_{BS} , whether for the purposes of increasing the gain of the Opamp, or simply to attain rail-to-rail input common mode, comes at the price of power dissipation.

The drain current of an active MOSFET transistor is given by:

$$I_D = \frac{m_n C_{ox}}{2} \frac{W}{L} (V_{GS} - V_T)^2 (1 + I V_{DS}) \quad (3.3.3)$$

When the V_T term is expanded to account for the Body effect, the equation becomes:

$$I_D = \frac{m_n C_{ox}}{2} \frac{W}{L} \left(V_{GS} - V_{T0} - g \sqrt{2f_F - V_{BS}} + g \sqrt{2f_F} \right)^2 (1 + I V_{DS}) \quad (3.3.4)$$

Equation 3.3.4 shows that, as V_{BS} increases, the V_{eff} term also increases, producing a larger drain current. Another drawback of this type of input stage is that as the bias voltage to the Bulk changes, the size of the depletion region between the Bulk and substrate changes. This means that the input capacitance will now be dependant on the input Bulk bias[10].

4. Conclusion

Four different approaches to designing a low voltage Opamp were presented in this paper.

1. The **folded cascode Opamp** is useful for moderately low supply voltages, at the cost of some extra current, but has limited performance in sub 1V applications, as well as a limited $V_{cm(in)}$.
2. The **complimentary input stage** helps to increase the input common mode voltage range, at the price of some extra transistors and current. However, it is susceptible to a dead-zone, where neither NMOS nor PMOS differential pairs are in the active region.
3. The **FGCMOS input stage** allows a rail-to-rail input common mode voltage range, at the cost of limited low frequency capabilities, and large, die area consuming capacitors.
4. The **Bulk driven amplifier input stage** allows a rail-to-rail input common mode voltage range, with substantial gain, at the cost of some extra power dissipation and a large Bulk bias dependant input capacitor.

All four options proposed in this paper have their own performance and cost tradeoffs, and some may be more useful for certain applications than others. As supply voltages continue to scale down, and performance demands increase, the decision to make these tradeoffs will become increasingly important and difficult.

5. References

- [1] Behzad Razavi, "Design of Analog CMOS Integrated Circuits", McGraw-Hill Higher Education, 2001.
- [2] Adel S. Sedra, Kenneth C. Smith, "Microelectronics Circuits Fourth Edition", Oxford University Press, 1998.
- [3] Ken Martin, "Digital Integrated Circuit Design", Oxford University Press, 2000.
- [4] Yang Wang, "Low voltage single-stage amplifier with wide output range", in 4th international conference of ASIC, pages 285-288, October 2001.
- [5] Falk Roewer and Ulrich Kleine, "A Novel Class of Complementary Folded-Cascode Opamps for Low Voltage", IEEE journal of solid-states circuits. Vol. 37, No.8., August 2002.
- [6] Chong-Gun Yu and Randall L. Geiger, "Very Low Voltage Operational Amplifiers Using Floating Gate MOS Transistors", IEEE international Symposium on Circuits and Systems (ISCAS), 1993.
- [7] Bradley A. Minch, "Evolution of a folded floating-gate differential pair", In the Proceedings of the 4th Midwest Symposium on Circuits and Systems, Vol.3 pages 1052-1056, August 2000.
- [8] Y. Berg, S.Aunet, O. Naess, H. Gundersen, M. Hovin, "A 0.3V floating-gate differential amplifier input stage with tuneable gain", 8th IEEE international Conference on Electronics, Circuits and Systems (IECS 2), pages 413-416 vol. 1, September 2001.
- [9] Benjamin J. Blalock, Philip E. Allen, Fellow, IEEE, and Gabriel A. Ricon-Mora, "Designing 1-V Op Amps Using Standard Digital CMOS Technology", IEEE transactions on circuits and systems II: Analog and digital Processing, Vol. 45, No.7, July 1998.
- [10] Troy Stockstad, Member, IEEE, and Hirokazu Yoshizawa, "A 0.9 V 0.5 uA Rail-to-Rail CMOS Operational Amplifier", IEEE journal of solid state circuits, Vol. 37, No.3, March 2002.

6. Figures




Figure 1. Standard NMOS Diffpair




Figure 2. Cascode Differential Amplifier




Figure 3. Folded Cascode Differential Amplifier





Figure 4. Complimentary Differential Input Schematic [5]



P input Opamp

Figure 5. Complimentary input Differential pair block diagram




Figure 6. Programing a Floating Gate Transistor




Figure 8. Floating gate Pseudodifferential Pair [7]




Figure 9. Floating gate Analog Inverter [7]




Figure 10. Floating Gate Analog Inverter Differential Pair [8]




Figure 11. Bulk driven Amplifier [10]




Figure 12. Bulk driven Opamp Schematic [10]